PTI Technologies Inc.



Warning: Information Subject to Export Control Laws

This document is controlled under jurisdiction of Export Administration Regulations (EAR), 15 CFR parts 730 to 772. Diversion contrary to U.S. law is prohibited

Situation And Need – Our View

- Aircraft cabin air comes from two sources
 - 50% "Fresh" Air (bleed air from engine / APU compressor section)
 - Exception is 787 ram air
 - 50% Recirculated Air from cabin
- The Recirculated Air is treated today HEPA Filters
 - Removes particulates, viruses, bacteria, fungus
 - Does not handle gases/odors need second media (activated carbon)
- However, "Fresh" Air really has no treatment except Ozone
- The "Fresh" Air component is the driver of air quality
 - Contains aerosols, VOC's, particulates and ozone
 - Creates health/safety issues for flight crew
 - Degrades passenger experience
 - No filtration/removal and low ozone conversion at lower temperatures

An Effective Solution For Bleed Air Filtration Is Needed



Potential VOC's In Engine Bleed Air

1.1.1-trichloroethane 1,1,2,2-tetrachloroethane 1.1.2-trichloro-1,2,2-trifluoroethane (Freon-113) 1.1.2-trichloroethane 1.1-dichloroethane 1,1-dichloroethene 1.2.4-trichlorobenzene 1,2,4-trimethylbenzenc 1,2-dibromoethane 1.2-dichlorobenzene 1,2-dichloroethane 1,2-dichloropropane 1,2-dichlorotetrafluoroethane (Freon-114) 1.3.5-trimethylbenzene 1,3-butadiene 1,3-dichlorobenzene 1.4-dichlorobenzene 1,4-dioxane 2,2,4-trimethylpentane 2.3-dimethylpentane 2-butanone (methyl ethyl ketone) 2-hexanone (methyl butyl ketone) 3-Methylhexane 4.4'methylene bis(o-chloroaniline) 4-ethyl toluene 6methyl5heptene2one acenaphthene acetaldehyde < acetone <acrolein 🗲 AHTN anthracene benzenc benzo(a)anthracene benzo(a)pyrene <-benzo(b)fluoranthene

benzo(k)fluoranthene benzyl acetate benzyl chloride bipbenyl bromodichloromethane bromoform (tribromomethane) butyl benzyl phthalate carbon disulfide carbon tetrachloride (tetrachloromethane) chlorobenzene chloroform (trichloromethane) chrysene cis-1,2-dichloroethene cis-1,3-dichloropropene cis-permethrin cyclohexane decanal di-2-ethyl hexyl phthalate dibenzo (a,h)anthracene dibromochloromethane dibutyl phthalate dichlorodifluoromethane (Freon-12) diethyl phthalate cthanol < othyl acetate ethyl chloride (chloroethane) ethylbenzene fluoranthene fluorene formaldehyde <-heptane hexachloro-1,3-butadiene hexane hexyl cinnemal HHCB Indeno(1,2,3-cd)pyrene isoprene (2-methyl-1,3-butadiene) isopropyl alcohol

limonene m&p-xylene methyl bromide (bromomethane) methyl chloride (chloromethane) methyl isobutyl ketone (4-methyl-2-pentanone) methyl methacrylate methyl tert-butyl ether methylevelohexane methylene chloride (dichloromethane) naphthalene ponanal octanal o-xylene PCB 11 PCB 52 phenanthrene phenethyl alcohol propene propionaldehyde Pyrene styrene Sumithrin tetrachloroethene tetrahydrofuran toluene trans-1,2-dichloroethene trans-1,3-dichloropropene trans-Permethrin trichloroethene trichlorofluoromethane (Freon 11) tri-m,m,p-cresyl phosphate tri-m,p,p-cresyl phosphate tri-m-cresyl phosphate tri-o-cresyl phosphate tri-p-cresyl phosphate tris(2-chloroethyl)phosphate tris(dichloro)phosphate vinyl acetate vinyl chloride (chloroethene)

Many Potential VOC's In Bleed Air – Complex Problem To Remove All



benzo(e)pyrene

benzo(ghi)perylene

Situation And Need – Our View

- What are the challenges for effective solution for Bleed Air?
 - Which VOC's to remove which possible ones to choose?
 - How to best remove aerosols (liquids, particulates)?
 - How to get better ozone conversion especially at low temperatures?
 - Packaging filter for aircraft (footprint, weight, certification, life)?
 - How to make installation easy (new, existing)?
 - How to make cost effective to install, operate and maintenance?
- Fortunately, there is a solution
 - New technology for bleed air in Fuel Tank Inerting Systems (FTIS)
 - Simple design, lower weight, long life, economical costs
 - Handles aerosols, VOC's, and ozone in a single envelope
 - Combined with recirc filters better cabin air quality
- Filter design tested ready to fit to aircraft, working with partners

Technology Now Tested And In Hand For Bleed Air Solution



What's At Stake

- Our industry flight crews
 - Contaminated air has impaired and incapacitated flight / cabin crew
- Our industry passengers
 - Exposure to chemicals, fumes and ozone public health risk
- Our industry manufacturers
 - Idea of filtration now new considered since 1950's but lack of solutions
- Air Accident Investigators globally and Law Courts
 - Contaminated air exposure risk to flight safety, crew and public health
 - Understanding of chemicals present during these exposure events
 - Increased financial and legal liability
 - Call on regulators / Governments to mandate effective "bleed air" filters and contaminated air warning sensors on passenger aircraft

Call To Action – Solutions Needed For Crew And Passengers




PTI's Pedigree In Air Filtration

- Who is PTI Technologies
 - World leader in aviation/aerospace filtration for over 60 years
 - Filtration for all aircraft fluids hydraulics, air/bleed air, fuel, water, lube
- Our experience and pedigree in air filtration
 - We have supplied air filtration for military aircraft since the 1980's
 - Special media developed to capture dangerous gases/chemicals/particulates
 - Continued development for military today cabin air and breathing air
 - Developed / certified of air filtration for Space Launch System (gases)
 - Developed / certified / in-service HEPA Cabin Air Filters for airlines
 - Developed / certified / in-service engine / APU bleed air filtration
 - Developed / tested filtration combined with custom absorbents
 - Developed / tested patented FTIS filtration (Aerosols, VOC's, HEPA, Ozone)

PTI Has Pedigree And Technology For Bleed Air Solution



Aerospace Product Applications






PTI's Solution To Bleed Air Filtration

- Solution Advanced Technology Filtration developed for FTIS
 - Removes Aerosols (Liquids, Particulates), Gases/VOC's, Ozone + HEPA
 - Incorporates multilayer media, active absorbent and ozone conversion
 - Proven patented technology and designs
- Tested to EN / ISO Standards
 - Aerosols (Liquids, Particulates)
 - Challenge Gases single and mixed
 - Ozone conversion








Bleed Air Filtration Testing – EN4618-2009

Category	Group	Compound	CAS No.	Bio- effluents	Cabin Interior	Solvents	External Conditions	Exhaust	Oils, Lubricants & Hydraulics	Fuel
Inorganic Compounds		Carbon Dioxide	124-38-9	<u> </u>			⊠ "	⊠ °		
		Carbon Monoxide *	630-08-0							
		Nitrogen Oxides ^b	10102-44-0					130		
		Ozone ^a	10028-15-6							
Inorganic / Organic Particles		Particles, aerosols		E *	E 2,0		◙	2	100	図
		Micro- organisms		≥ °	⊠°					
		Endotaxins		2 4	3 2		S			
Aliphatic Compounds	Alkanes	Methane ^b	74-82-8	2				2		Ø
	Ketones	Acetone *	67-64-1	d		3			□	
		Methyl Ethyl Ketone ^a	78-93-3			23			100	
	Aldehydes	Acetaldehyde *	75-07-0						□	
		Acrolein *	107-02-8					2	□	120
		Formaldehyde ^a	50-00-0		⊠*	3		2	■	Ø
	Halogen Derivatives	Methylene Chloride ^a	74-87-3			□				
Aromatic Compounds		Benzene *	71-43-2					<u> </u>		
		Tricresyl Phosphate ^b	1330-78-5							
		Toluene	108-88-3			D *				
Polycyclic Aromatic Hydrocarbons		Benzo (alpha) Pyrene ^b	50-32-8					<u> </u>		
		Naphthalene ^b	91-20-3					-		




Testing Results


AEROSOLS (fine solid particles / liquid droplets)




GAS ADSORPTION



OZONE







What's Next

Next step is to bring bleed air filtration in-service to airlines

- Specifications (bleed air, filtration) to optimize design / performance
- Prototypes / flight test program
- Certification STC and / or OEM
- Retrofits / new production
- Need airline partners collaborate on design/installation/test
- Need OEM support for simple solution
 - Certify across platforms
 - Create aftermarket support documentation, manuals

Technology Is In Hand To Address The Bleed Air Filtration Need



For More Information / Partnering

CONTACT:

David Conrad, VP, Business Development dconrad@ptitechnologies.com

+1 (805) 604-3844

